

How to– Step-by-Step Instructions for Moon Mud



Items you will need to start cementing.

- Small natural fiber brush- for filling lead and zinc channels
- Big natural fiber brush- for cleaning off absorbed cement and whiting after its cured
- Mixing cup- powder and liquid parts
- Whiting
- Picker- sharpened chopsticks, fiddle stick etc
- Luster brush or big natural fiber brush- polishing

1. Mix the Cement

- Pour the dry powder into a mixing bowl.
- Shake bottle, then slowly add the liquid part as needed while mixing.
- No set measurements are required, adjust liquid and powder to achieve your preferred consistency.
- You're aiming for a tar-like pudding-like consistency that spreads easily but isn't too runny.
- If the mixture feels too thin, add a small amount of whiting to thicken it up.

2. Apply to Panel

- Using a small natural fiber brush or gloved hand, apply the cement generously to one side of your panel.
- *Make sure* it gets packed well into all the lead or zinc channels.

3. Set Whiting (Side 1)

- Once the first side is fully cemented, sprinkle and mix Whiting generously across the entire surface.
- Let it sit for at least 30 minutes to begin setting.

4. Flip and Cement Side 2

- While the first side is setting, flip your panel and repeat the cementing process on the back.
- Sprinkle Whiting on the second side after applying the cement.

5. Set and Rest Both Sides

- Let the Whiting sit on both sides for 30 to 60 minutes. (Or preferred waiting time)
- This step helps absorb excess oil and allows the cement to begin curing.

6. Clean-Up and Detailing

- Once set, go through a cleaning cycle of brushing off excess cement and whiting with a large brush, vacuuming, picking, brushing again, pick, and vacuuming again.
- Picking: The process of removing excess cement from between the lead came and the glass using a pointed tool. This ensures the lead lines are clean and the cement is firmly packed for strength and durability.
- Buff or polish gently to clean the glass.

7. Cure Time

- Let the panel rest up to 10 hours to fully cure.
- **This is a fast curing product*****

8. Final Polish

- After curing, return to the piece and give it a final polish to remove any haze and finish the cleanup.

For any questions please contact Gritandglasss@gmail.com

Instagram: [Grit_and_glasss](#)

or call Blue Moon Glassworks in Austin, Texas at 512-380-0770.